



- (FR) Interrupteurs à coupure visible
- (GB) Load break switches with visible breaking
- (DE) Lasttrennschalter mit sichtbarer Trennung
- (IT) Interruttori di manovra - sezionatori modulari a comando rotativo
- (ES) Interruptores de corte visible

Notice d'instructions  
User instructions

Bedienungsanleitung

Istruzioni di montaggio

Instrucciones de uso

## HA304, HA404, HA305, HA405, HA306, HA406

	HA304 HA404	HA305 HA405	HA306 HA406
I <sub>th</sub> (40°C)	80A	100A	125A
U <sub>i</sub> (V)	690	690	690
U <sub>imp</sub> (kV)	8	8	8
AC (21A/400V)	80	100	125
AC (22A/400V)	80	100	125
AC (23A/400V)	63	63	63
I <sub>cc</sub> max (kA)	12	12	12
I <sub>cw</sub> (A)	2500	2500	2500
I <sub>ccF</sub> (kA)	100	100	50
gl - gG	80 A	100 A	125 A
	50 mm <sup>2</sup>	50 mm <sup>2</sup>	50 mm <sup>2</sup>

