

WARRANTY. The F&F products are covered by a varranty of the 24 months from the date of purchase. Effective only with proof of purchase. Contact your dealeror directly with us. More information how to make a compliant can be found on the website: www.fif.com.pl/reklamacie





Do not dispose of this di In accordance with the any household electro-w quantity to a collection p store in the event of purc regardless of brand). Elec in the bosom of nature pc blished for this purpose, w equipment (as per the ing n

Purpose

Electromagnetic relay in housing for direct installation in flush-mounted Ø60 box.

Relay version "i" is to pin adapted to cooperate with the receivers with high starting current, such as LED fluorescent lamps, ESL fluorescent lamps, electronic transformers, discharge lamps, etc.

Operation

Supply voltage applied to the relay closes the contact 1-2. This state is indicated by a green LED. After power failure, the contacts are opened. Installation

Disconnect the power supply.
Attach the relay in the flush-mounted box.

3. Connect the power supply: N to terminal 6; L to terminal 4 or 5. NOTE! For the same power source for relay and controlled receiver can

perform a "bridge" between the feed point 4/5 and the input terminal 2. 4. Power supply circuits of controlled receivers connect by pins 1-2 and 3-4.

- 1 -





Table of power

\ <u>ن</u>	÷			
incandescent	halogen	fluorescent	energy saving	LED
3000W	2500W	1500W	750W	750W

The above data are indicative and will depend to a large extent on the design of a specific receiver (especially for LED bulbs, energy saving lamps, electronic transformers and pulse power supplies), switching frequency and working conditions. For more information visit: www.fif.com.pl.

Connection scheme



- 2 -

D150410